

A PERFECT CONNECTION: PAIR AND GO!

BMP 8500 - THE TRENCH ROLLER.



BMP 8500: the trench roller.

1

STABLE CONNECTION THANKS TO RADIO.

- Trouble-free operation even under difficult job site conditions
- Clear and secure pairing of remote control to machine
- All important functions at a glance thanks to clearly visible LEDs





SIMPLE RADIO REMOTE EXCHANGE.

- Remote control unit easy to replace
- Pairing a replacement radio remote done in seconds Any remote can be used with any machine, increasing flexibility when a replacement is needed quickly



3

TELEMATICS – TRACK YOUR MACHINE'S STATUS.

As an option, the machine is just a mouse click away Monitor machine position and status, including error codes





FOR GREATER ON-SITE SAFETY.

BOMAG Operator Safety System (BOSS) reacts immediately Machine stops reliably if it comes too close to operator Visual signal warns operator of risk of machine tipping Manoeuvring out of danger zone then possible

5

6

YOU COULD HARDLY ASK FOR MORE CONVENIENCE.

- Battery charge status clearly visible on remote control display
- Remote control with two batteries
- Second battery can be charged while remote controls machine with the first
- Total runtime of both batteries: 35-40 hours







ECONOMIZER. COMPACTION CONTROL MADE EASY.

- Light strips show compaction progress
- System warns against over-compaction and grain breakage while identifying soft spots in the soil
- Reduces number of passes by up to 25%

BETTER PROTECTION FOR LONGER SERVICE LIFE.

- Enclosed exciter housing prevents water and dirt from entering
- Rugged, well-thought-out design for tough everyday construction site operation
- Intelligent layout of hydraulic hoses minimises repairs and keeps service costs low

8

QUICKLY WIDENED FOR ALL TASKS.

- Effortlessly widen or reduce working width from 610 mm to 850 mm
- Smooth drum optionally available

www.bomag.com

Head Office / Hauptsitz: BOMAG Hellerwald 56154 Boppard GERMANY Tel. +49 6742 100-0 info@bomag.com

BOMAG Maschinen-

handelsgesellschaft m.b.H. Klausenweg 654 2534 Alland AUSTRIA Tel. +43 2258 20202 austria@bomag.com

BOMAG (CANADA), INC.

2233 Argentia Road, East Tower Suites 302 Mississauga, ON, Canada L5N 2X7 Tel. +1 800 782 6624 canada@bomag.com

BOMAG (CHINA)

Compaction Machinery Co. Ltd. No. 2808 West Huancheng Road Shanghai Comprehensive Industrial Zone (Fengxian) Shanghai 201401 CHINA Tel. +86 21 33655566 china@bomag.com

BOMA Equipment

Hong Kong LTD Room 1003, 10/F Cham Centre 700, Castle Peak Road Kowloon HONG KONG Tel. +852 2721 6363 bomahk@bomag.com

BOMAG France S.A.S.

2, avenue du Général de Gaulle 91170 Viry-Châtillon FRANCE Tel. +33 1 69578600 france@bomag.com

BOMAG (GREAT BRITAIN), LTD.

Sheldon Way Larkfield, Aylesford Kent ME20 6SE GREAT BRITAIN Tel. +44 1622 716611 gb@bomag.com

BOMAG Italia

Via Roma 50 48011 Alfonsine ITALY Tel. +39 0544 864235 italy@bomag.com

FAYAT BOMAG Polska Sp. z o.o.

UI. Szyszkowa 52 02-285 Warszawa POLAND Tel. +48 22 482 04 00 poland@bomag.com

BOMAG APAC PTE LTD

300 Beach Road The Concourse, #18-06 Singapore 199555 SINGAPORE Tel. +65 6 294 1277 singapore@bomag.com

BOMAG Americas, Inc.

125 Blue Granite Parkway Ridgeway SC 29130 U.S.A. Tel. +1 803 3370700 usa@bomag.com

01/24 PRE 102 365 13.02.2024

